
WALL TEMPERATURE GUIDE

Degrees Above Room Temperature*





This illustration is for when the chase is vented. This can be done by either installing a grill on the front or sides of chase (for a chase that bumps out into a room) or be open at the top of the chase. (See installation manual for further information).

*Degrees above room temperature are surface temperatures of a TV mounted 1½" off the wall above the fireplace. This in no way indicates what the wall temperature above the fireplace is. Check with your TV manufacturer for normal operating temperatures.







S E R E N E ZERO CLEARANCE DIRECT VENT GAS FIREPLACE